


ITEM#	QTY	PART#	PART TITLE			
-8	1	RBEM652V3002102-8	GUIDE			
-9	2	RBEM652V3002102-9 STUD				
-10	1	RBEM652V3002102-10	V3002102-10 BAR HANDLE NUT			
-11	1	RBEM652V3002102-11	SCREW			
-12	1	RBEM652V3002102-12	PLATE ASSY			
-14	1	RBEM652V3002102-14	RBEM652V3002102-14 FOOT ASSY			
21	1	McMaster#98380A473 OR EQUIV.	416 SS DOWEL PIN 1/8" DIA. X 3/4" LG.			
22	1	McMaster#94895A815 OR EQUIV	ZINC YELLOW PLATED GRADE 8 STEEL HEX NUT 3/8"-24			
23	3	McMaster#60765K343 OR EQUIV	STEEL ROUND KNOB M8 X 1.25mm THROUGH X 25mm HEAD DIA.			
24	3	McMaster#95229A480 OR EQUIV	CAD PLATE STEEL WASHER 5/8" OD X 0.39" ID X 0.029-0.035 THK			
25	4	TRA-613	STEEL THRUST WASHER 0.377" ID. X 13/16" OD. X 0.032" THK.			
26	2	NTA-613	STEEL NEEDLE ROLLER THRUST BEARING 0.377" ID. X 13/16" OD. X 5/64" THK.			






11


D


С

- NOTES: 1) MATERIAL: N/A 2) HEAT TREAT: N/A 3) FINISH: N/A

- 7) ASSEMBLE AS SHOWN
- 8) APPLY LOCTITE 620 OR EQUIVALENT ON MATING SURFACES THEN PRESS FIT ITEM 21 WITH ITEM -10 AND ITEM -11 AND REMOVE EXCESS 9) APPLY RED THREADLOCKER LOCTITE 263/262 ON THREADS OF ITEM 22 THEN ASSEMBLE WITH ITEM -11, AND REMOVE EXCESS 10) ASSEMBLE ITEM 22 AND ITEM 23 HAND TIGHT 11) THE TOOL ASSY MUST BE PACKAGED WITH A DESICCANT BAG INTO A TIGHT FITTING SEALED PLASTIC BAG











DESIGN	VM	DART AER	OSPACE LTD		
DRAWN	VM	HAWKESBURY, ONTARIO, CANADA			
CHECKED	KPT	TOOL PART #		REV. A	
MFG. APPR.	JFC	RBEM652V3002102		SHEET 8 OF 17	
APPROVED	M	TITLE	SCALE		
	·	TAIL GEAR BOX INPUT SE	EAL EXCHANGE NTS		
DATE 2019	9-05-24	COPYRIGHT © 2019 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.			


5











.

WRITTEN PERMISSION FROM DART AEROSPACE

